B+K PRECISION 466

Supplement

CATHODE RAY TUBE TESTER/REJUVENATOR

B+K PRECISION
Product of DYNASCAN CORPORATION
6460 West Cortland Street, Chicago, Illinois 60635

CRT TESTER REJUVENATOR
SET-UP CHART

P/N 497-016-05-83

MODEL 466

COLOR

TUBE TYPE	HEATER VOLTAGE	ADAPTER SOCKET
6ABP1 ▲ ■	6.3	CR29 & SP66 (Use Special)
6ABP55 ▲ ■	6.3	CR-29 & SP66 (Use Special)
6ABP56 ▲ ■	6.3	CR29 & SP66 (Use Special)
13VAUP22 ▲ ■	6.3	CR18 & SP66 (Use Special)
13VBTP22 ▲	6.3	CR16 & SP66 (Use Direct)
17VBQP22 ▲	6.3	CR16 & SP66 (Use Direct)
17VCDP22 ▲	6.3	CR16 & SP66 (Use Direct)
19CD1000	6.3	3J
19VKJP22 ▲ ■	6.3	CR16 & SP66 (Use Special)
19VKLP22 ▲ ■	6.3	CR16 & SP66 (Use Speical)
19VKUP22 ▲ ■	6.3	CR23 & SP66 (Use Special)
19VKYP22 ▲ ■ ¢	6.3	CR28 & SP66 (Use Special)
19VKZP22 ▲ ■	6.3	CR16 & SP66 (Use Special)
19VLEP22 ▲ ■	6.3	CR25 & SP66 (Use Special)
19VLXP22 ▲ ■	6.3	CR23 & SP66 (Use Special)

▲ TEST SOCKET AND SP-66 AVAILABLE AS AN OPTIONAL ACCESSORY.

■ REFER TO SPECIAL INSTRUCTIONS FOR ADAPTER/CONVERTER SP-66

¢ RED AND BLUE GUNS INTERCHANGED

CRT TESTER REJUVENATOR
SET-UP CHART

P/N 497-016-05-83

MODEL 466

COLOR

TUBE TYPE	HEATER VOLTAGE	ADAPTER SOCKET
19VMLP22 ▲ ■	6.3	CR23 & SP66 (Use Special)
19VMRP22 ▲ ■	6.3	CR23 & SP66 (Use Special)
19VMZP22 ▲ ■	6.3	CR23 & SP66 (Use Special)
19VNBP22 ▲ ■	6.3	CR23 & SP66 (Use Special)
19VNCP22 ▲ ■	6.3	CR23 & SP66 (Use Special)
19VNFP22 ▲ ■	6.3	CR20 & SP66 (Use Special)
19VNGP22 ▲ ■	6.3	CR23 & SP66 (Use Special)
19VNJP22 ▲ ■	6.3	CR23 & SP66 (Use Special)
21VBMP22 ▲ ■	6.3	CR16 & SP66 (Use Special)
22AJP22	6.3	3J
22AQP22	6.3	3J
25VFJP22 ▲ ■	6.3	CR24 & SP66 (Use Special)
25VGQP22 ▲ ■	6.3	CR22 & SP66 (Use Special)
25VGWP22 ▲ ■	6.3	CR24 & SP66 (Use Special)
25VGYP22 ▲ ■	6.3	CR23 & SP66 (Use Special)

▲ TEST SOCKET AND SP-66 AVAILABLE AS AN OPTIONAL ACCESSORY.

■ REFER TO SPECIAL INSTRUCTIONS FOR ADAPTER/CONVERTER SP-66

¢ RED AND BLUE GUNS INTERCHANGED

CRT TESTER REJUVENATOR
SET-UP CHART

P/N 497-016-05-83

MODEL 466

COLOR

TUBE TYPE	HEATER VOLTAGE	ADAPTER SOCKET
25VHAP22▲■	6.3	CR22 & SP66 (Use Special)
25VHBP22▲■	6.3	CR20 & SP66 (Use Special)
25VHDP22▲■	6.3	CR23 & SP66 (Use Special)
25VHJP22▲■	6.3	CR22 & SP66 (Use Special)
25VHKP22▲■	6.3	CR24 & SP66 (Use Special)
25VHLP22▲■	6.3	CR20 & SP66 (Use Special)
25VHNP22▲■	6.3	CR22 & SP66 (Use Special)
25VHQP22▲■	6.3	CR22 & SP66 (Use Special)
25VHRP22▲■	6.3	CR20 & SP66 (Use Special)
25VHSP22▲■	6.3	CR24 & SP66 (Use Special)
25VHTP22▲■	6.3	CR20 & SP66 (Use Special)
25VHUP22▲■	6.3	CR24 & SP66 (Use Special)
180RB22-B▲■	6.3	CR26 & SP66 (Use Special)
180RB22-G▲■	6.3	CR26 & SP66 (Use Special)

▲ TEST SOCKET AND SP-66 AVAILABLE AS AN OPTIONAL ACCESSORY.

■ REFER TO SPECIAL INSTRUCTIONS FOR ADAPTER/CONVERTER SP-66

¢ RED AND BLUE GUNS INTERCHANGED

CRT TESTER REJUVENATOR
SET-UP CHART

P/N 497-016-05-83

MODEL 466

COLOR

TUBE TYPE	HEATER VOLTAGE	ADAPTER SOCKET
180RB22-R▲■	6.3	CR26 & SP66 (Use Special)
180YB22-B▲■	6.3	CR26 & SP66 (Use Special)
180YB22-R▲■	6.3	CR26 & SP66 (Use Special)
180YB43▲■	6.3	CR26 & SP66 (Use Special)
200TB22▲■	11.0	CR25 & SP66 (Use Special)
250AFB22▲■	6.3	CR25 & SP66 (Use Special)
320BSB22▲■	6.3	CR28 & SP66 (Use Special)
320BTB22▲■	6.3	CR25 & SP66 (Use Special)
320BXB22▲■	6.3	CR25 & SP66 (Use Special)
320CXB22▲■	6.3	CR23 & SP66 (Use Special)
320DKB22▲■	6.3	CR23 & SP66 (Use Special)
320DJB22▲■	6.3	CR23 & SP66 (Use Special)
370DNB22▲■	6.3	CR25 & SP66 (Use Special)
370EJB22▲■	6.3	CR25 & SP66 (Use Special)

▲ TEST SOCKET AND SP-66 AVAILABLE AS AN OPTIONAL ACCESSORY.

■ REFER TO SPECIAL INSTRUCTIONS FOR ADAPTER/CONVERTER SP-66

¢ RED AND BLUE GUNS INTERCHANGED

CRT TESTER REJUVENATOR
SET-UP CHART

P/N 497-016-05-83

MODEL 466

COLOR

TUBE TYPE	HEATER VOLTAGE	ADAPTER SOCKET
370ESB22 ▲ ■	6.3	CR28 & SP66 (Use Special)
370FHB22 ▲ ■	6.3	CR25 & SP66 (Use Special)
370FJB22 ▲ ■	6.3	CR25 & SP66 (Use Special)
370JSB22 ▲ ■	6.3	CR23 & SP66) (Use Special)
370JYB22 ▲ ■	6.3	CR23 & SP66 (Use Special)
370JZB22 ▲ ■	6.3	CR23 & SP66 (Use Special)
370LJB22 ▲ ■	6.3	CR23 & SP66 (Use Special)
370MCB22 ▲ ■	6.3	CR23 & SP66 (Use Special)
370NMB22 ▲ ■	6.3	CR23 & SP66 (Use Special)
420BGB22	6.3	3J
420BSB22 ▲ ■	6.3	CR25 & SP66 (Use Special)
420CEB22 ▲ ■	6.3	CR25 & SP66 (Use Special)
420CUB22 ▲ ■	6.3	CR28 & SP66 (Use Special)
420CYB22 ▲ ■	6.3	CR25 & SP66 (Use Special)
420FAB22 ▲ ■	6.3	CR25 & SP66 (Use Special)

▲ TEST SOCKET AND SP-66 AVAILABLE AS AN OPTIONAL ACCESSORY.

■ REFER TO SPECIAL INSTRUCTIONS FOR ADAPTER/CONVERTER SP-66

¢ RED AND BLUE GUNS INTERCHANGED

CRT TESTER REJUVENATOR
SET-UP CHART

P/N 497-016-05-83

MODEL 466

COLOR

TUBE TYPE	HEATER VOLTAGE	ADAPTER SOCKET
420FJB22 ▲ ■	6.3	CR25 & SP66 (Use Special)
420GMB22 ▲ ■	6.3	CR23 & SP66 (Use Special)
470HRB22 ▲ ■	6.3	CR25 & SP66 (Use Special)
470JWB22 ▲ ■	6.3	CR25 & SP66 (Use Special)
470KLB22	6.3	4L
470KRB22 ▲ ■	6.3	CR25 & SP66 (Use Special)
470LGB22 ▲ ■	6.3	CR25 & SP66 (Use Special)
470LVB22 ▲ ■	6.3	CR25 & SP66 (Use Special)
470MFB22 ▲ ■	6.3	CR25 & SP66 (Use Special)
510ABYB22 ▲ ■	6.3	CR23 & SP66 (Use Special)
510ACXB22 ▲ ■	6.3	CR23 & SP66 (Use Special)
510ACYB22 ▲ ■	6.3	CR23 & SP66 (Use Special)
510HRB22 ▲ ■	6.3	CR25 & SP66 (Use Special)
510JZB22 ▲ ■	6.3	CR25 & SP66 (Use Special)
510KJB22 ▲ ■	6.3	CR25 & SP66 (Use Special)

▲ TEST SOCKET AND SP-66 AVAILABLE AS AN OPTIONAL ACCESSORY.

■ REFER TO SPECIAL INSTRUCTIONS FOR ADAPTER/CONVERTER SP-66

¢ RED AND BLUE GUNS INTERCHANGED

CRT TESTER REJUVENATOR
SET-UP CHART

P/N 497-016-05-83

MODEL 466

COLOR

TUBE TYPE	HEATER VOLTAGE	ADAPTER SOCKET
510LNB22 ▲ ■	6.3	CR25 & SP66 (Use Special)
510LXB22 ▲ ■	6.3	CR25 & SP66 (Use Special)
510LYB22 ▲ ■	6.3	CR25 & SP66 (Use Special)
510NLB22 ▲ ■	6.3	CR25 & SP66 (Use Special)
510RZB22 ▲ ■	6.3	CR25 & SP66 (Use Special)
510SJB22 ▲ ■	6.3	CR28 & SP66 (Use Special)
510TDB22 ▲ ■	6.3	CR25 & SP66 (Use Special)
510TUB22 ▲ ■	6.3	CR25 & SP66 (Use Special)
510UJB22 ▲ ■	6.3	CR23 & SP66 (Use Special)
510UKB22 ▲ ■	6.3	CR25 & SP66 (Use Special)
510VSB22 ▲ ■	6.3	CR23 & SP66 (Use Special)
510VWB22 ▲ ■	6.3	CR23 & SP66 (Use Special)
510VXB22 ▲ ■	6.3	CR25 & SP66 (Use Special)
510XDB22 ▲ ■	6.3	CR23 & SP66 (Use Special)

▲ TEST SOCKET AND SP-66 AVAILABLE AS AN OPTIONAL ACCESSORY.

■ REFER TO SPECIAL INSTRUCTIONS FOR ADAPTER/CONVERTER SP-66

¢ RED AND BLUE GUNS INTERCHANGED

CRT TESTER REJUVENATOR
SET-UP CHART

P/N 497-016-05-83

MODEL 466

COLOR

TUBE TYPE	HEATER VOLTAGE	ADAPTER SOCKET
510XJB22 ▲ ■	6.3	CR23 & SP66 (Use Special)
510XTB22 ▲ ■	6.3	CR23 & SP66 (Use Special)
510XUB22 ▲ ■	6.3	CR25 & SP66 (Use Special)
510ZEB22 ▲ ■	6.3	CR23 & SP66 (Use Special)
560BLB22 ▲ ■	6.3	CR25 & SP66 (Use Special)
560CLB22 ▲ ■	6.3	CR25 & SP66 (Use Special)
560CMB22 ▲ ■	6.3	CR18 & SP66 (Use Special)
560DEB22 ▲ ■	6.3	CR23 & SP66 (Use Special)
560DHB22 ▲ ■	6.3	CR19 & SP66 (Use Special)
560EGB22 ▲ ■	6.3	CR23 & SP66 (Use Special)
670BCB22 ▲ ■	6.3	CR25 & SP66 (Use Special)
670BKB22 ▲ ■	6.3	CR25 & SP66 (Use Special)
670BLB22 ▲ ■	6.3	CR18 & SP66 (Use Special)
A33AAB20X ▲ ■	6.3	CR23 & SP66 (Use Special)

▲ TEST SOCKET AND SP-66 AVAILABLE AS AN OPTIONAL ACCESSORY.

■ REFER TO SPECIAL INSTRUCTIONS FOR ADAPTER/CONVERTER SP-66

¢ RED AND BLUE GUNS INTERCHANGED

CRT TESTER REJUVENATOR
SET-UP CHART

P/N 497-016-05-83

MODEL 466

COLOR

TUBE TYPE	HEATER VOLTAGE	ADAPTER SOCKET
A33AAB30X ▲ ■	6.3	CR23 & SP66 (Use Special)
A33AAL01X ▲ ■	6.3	CR25 & SP66 (Use Special)
A33AAL02X ▲ ■	6.3	CR25 & SP66 (Use Special)
A33AAL03X ▲ ■	6.3	CR25 & SP66 (Use Special)
A33AAS50X ▲ ■	6.3	CR25 & SP66 (Use Special)
A33ABD00X ▲ ■	6.3	CR16 & SP66 (Use Special)
A37-554X ▲ ■	6.3	CR25 & SP66 (Use Special)
A38AAB10X ▲ ■	6.3	CR24 & SP66 (Use Special)
A43AAZ00X ▲ ■	6.3	CR23 & SP66 (Use Special)
A47-556X ▲ ■	6.3	CR25 & SP66 (Use Special)
A48AAB20X ▲ ■	6.3	CR23 & SP66 (Use Special)
A48AAB21X ▲ ■	6.3	CR23 & SP66 (Use Special)
A48AAB30X ▲ ■	6.3	CR23 & SP66 (Use Special)
A48AAD10X ▲ ■	6.3	CR24 & SP66 (Use Special)

▲ TEST SOCKET AND SP-66 AVAILABLE AS AN OPTIONAL ACCESSORY.

■ REFER TO SPECIAL INSTRUCTIONS FOR ADAPTER/CONVERTER SP-66

¢ RED AND BLUE GUNS INTERCHANGED

CRT TESTER REJUVENATOR
SET-UP CHART

P/N 497-016-05-83

MODEL 466

COLOR

TUBE TYPE	HEATER VOLTAGE	ADAPTER SOCKET
A48AAG01X ▲ ■	6.3	CR23 & SP66 (Use Special)
A48AAK03X ▲ ■	6.3	CR23 & SP66 (Use Special)
A48AAK04X ▲ ■	6.3	CR23 & SP66 (Use Special)
A48AAK05X ▲ ■	6.3	CR23 & SP66 (Use Special)
A48AAN01X ▲ ■	6.3	CR23 & SP66 (Use Special)
A48AAN02X ▲ ■	6.3	CR23 & SP66 (Use Special)
A48AAP02X ▲ ■	6.3	CR23 & SP66 (Use Special)
A48AAR00X ▲ ■	6.3	CR23 & SP66 (Use Special)
A48AAR21X ▲ ■	6.3	CR23 & SP66 (Use Special)
A48AAR50X ▲ ■	6.3	CR23 & SP66 (Use Special)
A48ABE10X ▲ ■	6.3	CR24 & SP66 (Use Special)
A48EAB00X01 ▲ ■	6.3	CR24 & SP66 (Use Special)
A48EAB00X02 ▲ ■	6.3	CR24 & SP66 (Use Special)
A51-213X ▲ ■	6.3	CR15 & SP66 (Use Special)

▲ TEST SOCKET AND SP-66 AVAILABLE AS AN OPTIONAL ACCESSORY.

■ REFER TO SPECIAL INSTRUCTIONS FOR ADAPTER/CONVERTER SP-66

¢ RED AND BLUE GUNS INTERCHANGED

CRT TESTER REJUVENATOR
SET-UP CHART

P/N 497-016-05-83

MODEL 466

COLOR

TUBE TYPE	HEATER VOLTAGE	ADAPTER SOCKET
A51-214X ▲ ■	6.3	CR15 & SP66 (Use Special)
A51-232X ▲ ■	6.3	CR24 & SP66 (Use Special)
A51-270X ▲ ■	6.3	CR18 & SP66 (Use Special)
A51-556X ▲ ■	6.3	CR25 & SP66 (Use Special)
A56-150X	6.3	7N
A56-270X	6.3	CR18 & SP66 (Use Special)
A56-280X ▲ ■	6.3	CR24 & SP66 (Use Special)
A56-540X ▲	6.3	CR21 & SP66 (Use Direct)
A56-705X ▲ ■	6.3	CR24 & SP66 (Use Special)
A63AAD10X ▲ ■	6.3	CR24 & SP66 (Use Special)
A63AAM02X ▲ ■	6.3	CR23 & SP66 (Use Special)
A63AAT30X ▲ ■	6.3	CR24 & SP66 (Use Special)
A63AAT31X ▲ ■	6.3	CR23 & SP66 (Use Special)
A67-705X ▲ ■	6.3	CR24 (Use Special)
E2581A ▲ ■	6.3	CR23 & SP66 (Use Special)

▲ TEST SOCKET AND SP-66 AVAILABLE AS AN OPTIONAL ACCESSORY.

■ REFER TO SPECIAL INSTRUCTIONS FOR ADAPTER/CONVERTER SP-66

¢ RED AND BLUE GUNS INTERCHANGED

CRT TESTER REJUVENATOR
SET-UP CHART

P/N 497-016-05-83

MODEL 466

COLOR

TUBE TYPE	HEATER VOLTAGE	ADAPTER SOCKET
M23JBA00X	6.3	4L
M37-120X	6.3	CR24 & SP66 (Use Special)

▲ TEST SOCKET AND SP-66 AVAILABLE AS AN OPTIONAL ACCESSORY.

■ REFER TO SPECIAL INSTRUCTIONS FOR ADAPTER/CONVERTER SP-66

¢ RED AND BLUE GUNS INTERCHANGED

CRT TESTER REJUVENATOR
SET-UP CHART

P/N 497-016-05-83

MODEL 466

B&W

TUBE TYPE	HEATER VOLTAGE	ADAPTER SOCKET
4M33P-M	12.0	2D
5M140P-M	12.0	2D
5VAHP4	6.0	2D
7M151P-M	12.0	2D
9M25P-M	6.3	2D
9VAJP4 ■	11.0	2D
9VBCP4	11.0	2D
10WP7A	6.3	REG.
12M149P-M	12.6	2D
15M24P-M	6.3	REG.
15VAXP4	11.0	2D
16VDHP4	12.0	2D
16VDJP4	11.0	2D
21M131P-M	6.3	REG.
110CB4 ▲	11.5	5E
140BJB4	11.0	2D
140BSB4	12.0	2D
140BXB4	6.3	2D
140DVB4	12.6	2D
230CLB4 **	12.0	2D
310GAB4	11.0	2D
310JMB4 **	12.0	2D
310JXB4 **	12.0	2D

**SET G1 TO 30V

■ SET G1 TO 70V

▲ TEST SOCKET AND SP-66 ADAPTER/ CONVERTOR, AVAILABLE AS AN OPTIONAL ACCESSORY

CRT TESTER REJUVENATOR
SET-UP CHART

P/N 497-016-05-83

MODEL 466

B&W

TUBE TYPE	HEATER VOLTAGE	ADAPTER SOCKET
310JZB4 **	12.0	2D
310KAB4 **	12.0	2D
340BHB4 **	12.0	2D
370LCB4 **	6.3	2B
370LDB4 **	6.3	2E
A31-270W	11.0	2D
A31-280W	11.0	2D
A47-330W	6.3	2B
C5M75P4	12.0	2D
C5M92P4	12.0	2D
C8M46P4	12.0	2D
C9M53P4	12.0	2D
C9M54P4	12.0	2D
C9M60P4	12.0	2D
C12M02P4	12.0	2D
C12M21P4	12.0	2B
C12M27P4	6.3	2B
C12M34P4	12.0	2D
C14M37P4	12.0	2B
C14M45P4	12.0	2D
C15M18P4	6.3	2E
C15M22P4	6.3	2B
C316P4	12.0	5E

** SET G1 TO 30V

■ SET G1 TO 70V

▲ TEST SOCKET AND SP-66 ADAPTER/ CONVERTOR, AVAILABLE AS AN OPTIONAL ACCESSORY

CRT TESTER REJUVENATOR
SET-UP CHART

P/N 497-016-05-83

MODEL 466

B&W

TUBE TYPE	HEATER VOLTAGE	ADAPTER SOCKET
C505P4	12.0	2D
C537P4	12.0	2D
C550P4	12.0	2D
C816P4	12.0	2D
C822P4	12.0	2D
C824P4	12.0	2D
C-935P4	12.0	2D
C938P4	12.0	2D
C1012P4	12.0	2D
C1270P4	12.0	2D
C1272P4	12.0	2D
C1289P4	12.0	2D
C1423P4	6.3	2B
C1427P4	12.0	2D
C1720P4	6.3	2B
E2112	6.3	2B
E2117A	11.0	2D
E2148	11.0	2D
E2173	11.0	2D
E2280	6.0	2D
E2675	6.3	2B
E2709	6.3	2B
E2710	12.6	2D

**SET G1 TO 30V

■ SET G1 TO 70V

▲ TEST SOCKET AND SP-66 ADAPTER/ CONVERTOR, AVAILABLE AS AN OPTIONAL ACCESSORY

CRT TESTER REJUVENATOR
SET-UP CHART

P/N 497-016-05-83

MODEL 466

B&W

TUBE TYPE	HEATER VOLTAGE	ADAPTER SOCKET
E2719	12.6	2D
E2720	12.6	2D
E2728	12.0	2D
E2732	12.6	2D
E2735	12.6	2D
E2759	12.0	2D
E2763	12.0	2D
E2797	12.0	2D
E2800	6.3	2B
E2809	6.3	2B
M23-190	11.0	2D
M23-290	6.3	2B
M24-190	11.0	2D
M24-192	11.0	2D
M24-290	6.3	2B
M24-306	12.0	2D
M24-307	12.0	2D
M31-110	11.0	2D
M31-190	11.0	2D
M31-210	6.3	2B
M31-290	6.3	2B
M31-320	6.3	2B
M31-335	12.0	2D

**SET G1 TO 30V

■ SET G1 TO 70V

▲ TEST SOCKET AND SP-66 ADAPTER/ CONVERTOR, AVAILABLE AS AN OPTIONAL ACCESSORY

CRT TESTER REJUVENATOR
SET-UP CHART

P/N 497-016-05-83

MODEL 466

B&W

TUBE TYPE	HEATER VOLTAGE	ADAPTER SOCKET
M31-336	12.0	2D
M31-340	12.0	2D
M37-110	11.0	2D
M38-210	6.3	2B
M38-290	6.3	2B
M38-320	6.3	2B
M44-110	11.0	2D
M44-210	6.3	2B
M50-110	11.0	2D
M50-210	6.3	2B
M61-210	6.3	2B
ST5490	6.3	2B
ST6107	12.0	2D
ST6124	6.3	2B
ST6152	12.0	2D
ST6158	6.3	2B
ST6162	6.3	2B
ST6168	12.0	2D
ST6170	6.3	2B
ST6172	6.3	2B
ST6173	12.6	2B
ST6183	6.3	2B
ST6197	6.3	2B

** SET G1 TO 30V

■ SET G1 TO 70V

▲ TEST SOCKET AND SP-66 ADAPTER/ CONVERTOR, AVAILABLE AS AN OPTIONAL ACCESSORY

CRT TESTER REJUVENATOR
SET-UP CHART

P/N 497-016-05-83

MODEL 466

B&W

TUBE TYPE	HEATER VOLTAGE	ADAPTER SOCKET
ST6198	6.3	2B
ST6199	12.0	2D
ST6600	12.0	2D

** SET G1 TO 30V

■ SET G1 TO 70V

▲ TEST SOCKET AND SP-66 ADAPTER/ CONVERTOR, AVAILABLE AS AN OPTIONAL ACCESSORY

DYNASCAN CORPORATION
6460 West Cortland Street
Chicago, Illinois 60635